



Digital Phone

Smart Steps

1. Ensure that all phones/equipment are on hook.
2. Verify that there is power to the APC power unit, DSL modem and Innomedia device.
3. Unplug power to the DSL Modem, and Innomedia device. Wait 30 seconds and plug the power cable back in. Test phone to verify dial tone.
4. Disconnect the existing cable from Phone1/Phone 2 on the Innomedia device. Connect a phone directly into phone into the same jack and check for dial tone.

