



Traditional Phone (Sacramento Area)

Smart Steps

1. Ensure that all phones/equipment are on hook.
2. Verify that there is power to the APC power unit.

Go to <http://support.surewest.com> for more helpful tips.

